


HONDA



50

MODEL Z50M




3

PARTS LIST

HONDA GENUINE PARTS

HONDA
GENUINE PARTS




APPLICATION OF PARTS LIST

This is a list of parts used on the HONDA 50
Model Z50M

1. How to read the Part Number

The composition of Part Number is as follows:

(Example)



2. How to Order Parts

When placing orders to us, inform us the correct part number by referring to this Parts List.

When changing parts, check the frame number, then the parts used can be found.

3. Regarding the News Number

News number is the number of the Parts News issued by Honda Service Division. Refer to the Parts News when you need to know the contents of modified parts and related parts in detail.

4. This Parts List can be revised with Revision Sheet

Keep this Parts List up-to-date by replacing or inserting Revision Sheets issued periodically.

Please put the Revision Sheet in the place of each page according to instruction shown at the bottom of the sheet.

If you make sure of this, the Parts List will be kept always up-to-date.

5. This Parts List was compiled as of 20th November, 1968 and covers the changes announced by the Parts News up to No. 8022.

HONDA MOTOR CO., LTD.
SERVICE DIVISION




CONTENTS

ENGINE GROUP

Ref. No.	Nomenclature	Page
E- 1.....	Cylinder • Cylinder Head	2
E- 2.....	Crankshaft • Piston	4
E- 3.....	Camshaft • Valve	6
E- 4.....	Cam Chain • Cam Chain Tensioner	8
E- 5.....	Crankcase • Cylinder Stud	10
E- 6.....	Clutch	12
E- 7.....	Oil Pump • Right Crankcase Cover	16
E- 8.....	Transmission	18
E- 9.....	Gear Change	20
E-10.....	Gear Shift.....	22
E-11.....	Left Crankcase Cover • Dynamo	24
E-12.....	Carburetor	26

FRAME GROUP

F- 1.....	Steering Handle	30
F- 2.....	Front Fork	32
F- 3.....	Fuel Tank.....	34
F- 4.....	Seat.....	36
F- 5.....	Frame Body • Air Cleaner.....	38
F- 6.....	Muffler • Step.....	40
F- 7.....	Tool • Tail Light	42
F- 8.....	Front Wheel	46
F- 9.....	Rear Wheel	48
F-10.....	Head Light • Wire Harness	50
Y	Support Stand	54
	Part No. Index	57





E-1 Cylinder · Cylinder Head

HONDA

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	12101-041-680	CYLINDER	1	Z50M-100001	Z50M-101006	
	12101-041-682	(Superseded by 12101-041-030)				8013
	12101-041-030	CYLINDER	1	Z50M-101007		
2	12191-035-010	GASKET, cylinder	1	Z50M-100001		
3	12200-036-030	HEAD, cylinder	1	Z50M-100001	Z50M-100999	
	12200-041-020	HEAD, cylinder	1	Z50M-101000		7025
4	12251-036-000	GASKET, cylinder head	1	Z50M-100001	Z25M-101006	
	12251-036-010	GASKET, cylinder head	1	Z50M-101007		
5	12301-035-000	COVER, cylinder head	1	Z50M-100001		
6	12331-035-000	COVER, right side, cylinder head	1	Z50M-100001		
7	12341-035-000	COVER, left side, cylinder head	1	Z50M-100001		
8	12361-035-000	CAP, tappet adjusting hole	2	Z50M-100001		
9	12391-035-000	GASKET, cylinder head cover	1	Z50M-100001		
10	12394-035-000	GASKET, cylinder head right side cover	1	Z50M-100001		
11	12395-035-000	GASKET, cylinder head left side cover	1	Z50M-100001		
12	16201-040-000	GASKET, insulator	2	Z50M-100001	Z50M-100999	
	16201-045-000	GASKET, insulator	2	Z50M-101000		7025
13	16211-045-000	INSULATOR, inlet pipe	1	Z50M-100001	Z50M-100999	
	16211-045-010	INSULATOR, inlet pipe	1	Z50M-101000		7025
14	17111-045-030	PIPE, inlet	1	Z50M-100001	Z50M-100999	
	17111-045-040	PIPE, inlet	1	Z50M-101000		7025
15	90082-035-000	BOLT, H.S., 6 mm	3	Z50M-100001		
16	90442-035-000	WASHER, sealing, 6 mm	3	Z50M-100001		
17	90443-035-000	WASHER A, sealing, 6 mm	2	Z50M-100001		
18	91302-001-020	O RING, 31.5 mm	2	Z50M-100001		
19	91303-035-000	PACKING, rubber, 16 mm	2	Z50M-100001		
20	91306-035-000	GASKET, rubber, 7.5 mm	1	Z50M-100001		
21	92700-0603230	STUD, 6×30	2	Z50M-100001		7037
22	92712-0602510	STUD, 6×25	2	Z50M-100001		
23	94301-08140	PIN, knock, 8×14A	2	Z50M-100001		
24	92000-06025	BOLT, hex., 6×25	2			
25	92000-06111	BOLT, hex., 6×111	1			
26	93700-06010	SCREW, cross, 6×10	2			
27	94001-06000	NUT, hex., 6 mm	3			
28	94021-06000	NUT, blind, 6 mm	3			

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
	13000-041-010	CRANKSHAFT ASSY.	1	Z50M-100001	Z50M-101200	
	13000-041-030	CRANKSHAFT ASSY.	1	Z50M-101201		8001
1	13010-036-000	RING-SET, piston (S.T.D.)	1	Z50M-100001		
	13020-036-000	RING SET, piston (0.25)	1	Z50M-100001		7034
	13030-036-000	RING SET, piston (0.50)	1	Z50M-100001		
	13040-036-000	RING SET, piston (0.75)	1	Z50M-100001		
	13050-036-000	RING SET, piston (1.00)	1	Z50M-100001		
2	13101-036-010	PISTON (S.T.D.)	1	Z50M-100001		
	13102-036-010	PISTON (0.25)	1	Z50M-100001		7034
	13103-036-010	PISTON (0.50)	1	Z50M-100001		
	13104-036-010	PISTON (0.75)	1	Z50M-100001		
	13105-036-010	PISTON (1.00)	1	Z50M-100001		
3	13111-036-000	PIN, piston	1	Z50M-100001		
4	13115-001-000	CLIP, piston pin	2	Z50M-100001		
5	13201-036-000	ROD, connecting	1	Z50M-100001		
6	13211-035-000	RETAINER, roller	1	Z50M-100001		
7	13310-035-030	CRANKSHAFT, right	1	Z50M-100001	Z50M-101200	
	13310-035-050	CRANKSHAFT, right	1	Z50M-101201		
8	13321-041-010	CRANKSHAFT, left	1	Z50M-100001	Z50M-101200	
	13321-041-020	CRANKSHAFT, left	1	Z50M-101201		
9	13381-035-010	PIN, crank	1	Z50M-100001		
10	14311-035-000	SPROCKET, timing	1	Z50M-100001		
11	22911-035-010	COLLAR, 17 mm	1	Z50M-100001		
12	90741-035-000	KEY, woodruff	1	Z50M-100001		
13	91001-035-000	BEARING, ball, 6304	2	Z50M-100001		
14	91101-001-030	ROLLER, 2.5×10	22	Z50M-100001		







E-3 Camshaft · Valve

HONDA

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	12021-035-811	GUIDE, inlet valve	1	Z50M-100001		
2	12023-051-310	GUIDE, exhaust valve	1	Z50M-100001		
3	14101-040-000	CAMSHAFT	1	Z50M-100001	Z50M-100999	
	14101-041-000	CAMSHAFT	1	Z50M-101000	Z50M-101591	7025
	14101-041-010	CAMSHAFT	1	Z50M-101592		
4	14431-035-000	ARM, valve locker	2	Z50M-100001		
5	14451-035-000	SHAFT, valve locker arm	2	Z50M-100001		
6	14711-036-000	VALVE, inlet	1	Z50M-100001		
7	14721-036-000	VALVE, exhaust	1	Z50M-100001		
8	14730-028-000	SEAL, valve stem	1	Z50M-100001		
9	14731-028-000	CAP, valve stem seal	1	Z50M-100001		
10	14751-035-600	SPRING, valve (outer)	2	Z50M-100001		
11	14761-035-000	SPRING, valve (inner)	2	Z50M-100001		
12	14771-035-600	RETAINER, valve spring	2	Z50M-100001		
13	14776-028-000	SEAT, inner valve spring	1	Z50M-100001		
14	14781-001-010	COTTER, valve	4	Z50M-100001		
15	90012-200-000	SCREW, tappet adjusting	2	Z50M-100001		
16	90206-001-000	NUT, tappet adjusting	2	Z50M-100001		
17	91306-028-000	O RING, 9.5×1.6.....	2	Z50M-100001		
18	98056-57711	PLUG, sparking (N.G.K.)	1	Z50M-100001		

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	14321-035-000	(Superseded by 14321-035-010)	1			
	14321-035-010	SPROCKET, cam.....	1	Z50M-100001		
2	14401-035-005	CHAIN, cam.....	1	Z50M-100001		
3-1	14500-035-000	ARM, cam chain tensioner	1	Z50M-100001	Z50M-101700	
3	14500-035-010	ARM, tensioner	1	Z50M-101701		7026
4	14502-035-310	ROLLER, cam chain tensioner	1	Z50M-101701		7026
5	14531-035-000	PIVOT, cam chain tensioner	1	Z50M-100001		
6	14541-035-010	SPRING, tensioner	1	Z50M-100001		W/009
7-1	14551-035-010	ROD, tensioner push	1	Z50M-100001	Z50M-101200	
7	14551-035-020	ROD, tensioner push	1	Z50M-101201		7021
8	14566-035-000	RUBBER, tensioner push rod head	1	Z50M-100001		
9	14591-035-010	VALVE, check	1	Z50M-100001		W/009
10	14610-035-010	ROLLER, cam chain guide	1	Z50M-100001		
11	14615-035-000	PIN, guide roller	1	Z50M-100001		
12	14670-035-030	SPROCKET, cam chain guide.....	1	Z50M-100001		
13	14675-035-050	SPINDLE, cam chain guide sprocket ...	1	Z50M-100001	Z50M-101200	
	14675-035-060	SPINDLE, cam chain guide sprocket ...	1	Z50M-101201		
14	90081-035-000	BOLT, sealing, 14 mm	1	Z50M-100001		
15	90083-035-000	BOLT, knock, 5 mm	3	Z50M-100001		
16	90441-035-000	WASHER, sealing, 14 mm	1	Z50M-100001		
17	90481-035-000	WASHER, 8 mm	1	Z50M-100001		







E-5 Crankcase · Cylinder Stud

HONDA

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	11100-045-000	CRANKCASE, right	1	Z50M-100001		
2	11191-035-030	GASKET, left crankcase	1	Z50M-100001		W/009
3	11200-045-000	CRANKCASE, left	1	Z50M-100001	Z50M-101200	
	11200-045-040	CRANKCASE, left	1	Z50M-101201		7021
4	15421-035-010	SCREEN, oil filter	1	Z50M-100001		
5	15761-045-000	PIPE, breather	1	Z50M-100001		
6	16236-045-000	CLAMPER, over flow pipe	1	Z50M-100001		
7	90031-035-010	STUD, cylinder	2	Z50M-100001		
8	90032-035-000	STUD B, cylinder	2	Z50M-100001		
9	90407-259-000	PACKING, drain cock	1	Z50M-100001		
10	91203-035-000	OIL-SEAL, 17-25-9	1	Z50M-100001		
11	91203-001-000	OIL-SEAL, S11.6-24-10.....	1	Z50M-100001		
12	92700-06024	STUD, 6×24	2	Z50M-100001		7037
13	92800-12000	BOLT, drain cock	1	Z50M-100001		
14	94301-10140	PIN, knock, 10×14A	2	Z50M-100001		
15	94301-08120	PIN, knock, 8×12A	2	Z50M-100001		
16	96100-62030	BEARING, ball, 6203	2	Z50M-100001		
17	93500-0604820	SCREW, cross, 6×48	1			
18	93500-0606020	SCREW, cross, 6×60	3			
19	93500-0606520	SCREW, cross, 6×65	4			

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	22101-040-000	OUTER, clutch.....	1	Z50M-100001	Z50M-100110	
	22101-040-010	OUTER, clutch.....	1	Z50M-100111		W/007
2	22111-040-000	COVER, clutch outer	1	Z50M-100001		
3	22119-040-000	GASKET, clutch outer cover	1	Z50M-100001		
4	22120-040-010	CENTER, clutch	1	Z50M-100001	Z50M-101075	
	22120-040-020	CENTER, clutch	1	Z50M-101076		7016
5	22131-035-020	GUIDE, clutch center.....	1	Z50M-100001		
6	22201-040-000	DISK, clutch friction	2	Z50M-100001		
7	22310-001-020	PLATE A, clutch.....	1	Z50M-100001	Z50M-103865	
	22310-041-010	PLATE A, clutch.....	1	Z50M-103866		8008
8	22321-001-030	PLATE B, clutch.....	1	Z50M-100001	Z50M-101006	
	22321-041-000	PLATE B, clutch.....	1	Z50M-101007		7020
9	22331-023-000	(Superseded by 22331-041-000)	1	Z50M-100001	Z50M-101006	
	22331-041-000	PLATE C, clutch.....	1	Z50M-101007		7020
10	22351-040-010	PLATE, drive	1	Z50M-100001	Z50M-100110	
	22351-040-020	(Superseded by 22351-040-060)				
	22351-040-060	PLATE, drive	1	Z50M-100111		8002
11	22401-040-000	SPRING, clutch	4	Z50M-100001	Z50M-100110	
	22401-040-010	SPRING, clutch	4	Z50M-100111		W/007
12	22411-001-010	SPRING, clutch free	4	Z50M-100001	Z50M-100999	
	22411-041-000	SPRING, clutch free	4	Z50M-101000		7025
13	22421-040-000	SPRING, clutch damper	4	Z50M-100001		
14	22811-040-010	LEVER, clutch	1	Z50M-100001	Z50M-101200	
	22811-040-020	LEVER, clutch	1	Z50M-101201		
15	22820-041-000	PLATE, clutch cam	1	Z50M-100001	Z50M-104279	
	22820-046-000	PLATE, clutch cam	1	Z50M-104280		8009
16	22825-046-000	SPRING, cam plate side	1	Z50M-100001		
17	22860-046-000	(Superseded by 22860-041-000)	1	Z50M-100001	Z50M-102782	
	22860-041-000	RETAINER, ball	1	Z50M-102783		7014
18	22901-001-000	SET-RING, 101.5 mm.....	1	Z50M-100001		
19	22901-040-000	SET-RING, 45 mm	1	Z50M-100001	Z50M-112392	
	90602-041-000	CIRCLIP, 45 mm	1	Z50M-112393		8016
20	23110-036-000	GEAR, primary driven	1	Z50M-100001		







E-6 Clutch**HONDA**

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
21	23112-041-000	GEAR, outer, drive	1	Z50M-100001	Z50M-101075	
	23112-041-020	(Superseded by 23112-041-030)	1			7016
	23112-041-030	GEAR, outer, drive	1	Z50M-101076		
22	23120-036-010	GEAR, primary drive.....	1	Z50M-100001		
23	25551-040-007	THROUGH, oil	1	Z50M-100001		8021
24	25555-033-000	(Superseded by 25555-046-000)	1			
	25555-046-000	SPRING, oil through	1	Z50M-100001		
25	90231-001-000	(Superseded by 90231-041-000)	1			
	90231-041-000	NUT, lock, 14 mm	1	Z50M-100001		
26	90431-001-000	WASHER, lock, 14 mm	1	Z50M-100001		
27	90482-001-010	WASHER, 12.2 mm.....	1	Z50M-100001	Z50M-101200	
28	90483-040-000	WASHER, stopper	4	Z50M-100001		
29	90601-001-000	CIR-CLIP, 17 mm	1	Z50M-100001		
30	96100-60000	BEARING, ball, 6000	1	Z50M-100001		
31	91102-001-010	ROLLER, 8×10	8	Z50M-100001		
32	93500-05008	SCREW, cross, 5×8	4			
33	93600-05010	SCREW, cross, 5×10	3			

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	11330-045-010	COVER, right crankcase	1	Z50M-100001		
2	11394-035-000	GASKET, right crankcase cover.....	1	Z50M-100001		
3	15119-035-020	GASKET, oil pump body	1	Z50M-100001		
	15300-035-000	PUMP ASSY., oil	1	Z50M-100001		
4	15311-035-000	BODY, oil pump	1	Z50M-100001		
5	15321-035-000	COVER, oil pump	1	Z50M-100001		
6	15329-035-000	GASKET, oil pump cover	1	Z50M-100001		
7	15331-035-000	ROTOR, inner, oil pump	1	Z50M-100001		
8	15332-035-000	ROTOR, outer, oil pump	1	Z50M-100001		
9	15382-035-000	SHAFT, oil pump drive	1	Z50M-100001		
10	15383-035-000	PIN, oil pump knock	1	Z50M-100001		
11	91311-044-000	O RING, 18×2.....	1	Z50M-100001	Z50M-103510	
	91307-035-000	O RING, 18×3.....	1	Z50M-103511		8004
12	15650-045-000	GAUGE, oil	1	Z50M-100001		
13	22830-041-000	PLATE, clutch lifter	1	Z50M-100001		
14	22846-040-000	BOLT, clutch adjusting	1	Z50M-100001		8005
	28300-045-000	ARM ASSY., kick starter	1	Z50M-100001		
15	28301-045-000	ARM, kick starter	1	Z50M-100001		
16	28302-001-000	PEDAL, kick starter	1	Z50M-100001		
17	28303-001-000	WASHER, kick starter knuckle	1	Z50M-100001		
18	28311-001-000	RUBBER, kick starter	1	Z50M-100001		
19	28322-001-000	SPRING, kick starter knuckle.....	1	Z50M-100001		
20	28324-001-000	CLIP, kick starter knuckle	1	Z50M-100001		
21	90281-001-000	NUT, 8 mm	1	Z50M-100001		
22	90485-040-000	WASHER, 8 mm	1	Z50M-100001		
23	91202-216-000	OIL-SEAL, SB type, 14-24-5	1	Z50M-100001		
24	91303-001-000	O RING, 8φ	1	Z50M-100001		
25	92000-06016	BOLT, hex., 6×16	3			
26	92000-06022	BOLT, hex., 6×22	1			
27	93500-05010	SCREW, cross, 5×10	3			
28	93500-0603820	SCREW, cross, 6×38	6			
29	93500-0606520	SCREW, cross, 6×65	2			
30	94111-05000	WASHER, spring, 5 mm	3			









E-8 Transmission

HONDA

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	23211-041-000	(Superseded by 23211-041-010)	1	Z50M-100001	Z50M-101200	
	23211-041-010	SHAFT, main, transmission	1	Z50M-101201	Z50M-103163	7019
	23211-041-020	SHAFT, main, transmission	1	Z50M-103164		7024
2	23221-041-000	SHAFT, counter, transmission.....	1	Z50M-100001	Z50M-101200	
	23221-041-010	SHAFT, counter, transmission.....	1	Z50M-101201	Z50M-103163	7019
	23221-041-040	SHAFT, counter, transmission.....	1	Z50M-103164		7024
3	23421-041-000	GEAR, low, counter shaft.....	1	Z50M-100001		
4	23431-041-010	GEAR, second, main shaft	1	Z50M-100001	Z50M-102781	
	23431-041-030	GEAR, second, main shaft	1	Z50M-102782	Z50M-103163	7013
	23431-041-040	GEAR, second, main shaft	1	Z50M-103164		7024
5	23441-041-000	GEAR, second, counter shaft	1	Z50M-100001	Z50M-102781	
	23441-041-050	GEAR, second, counter shaft	1	Z50M-102782	Z50M-103163	7013
	23441-041-060	GEAR, second, counter shaft	1	Z50M-103164		7024
6	23471-041-000	GEAR, top, main shaft	1	Z50M-100001	Z50M-102781	
	23471-041-030	GEAR, top, main shaft	1	Z50M-102782	Z50M-103163	7013
	23471-041-040	GEAR, top, main shaft	1	Z50M-103164		7024
7	23481-041-000	(Superseded by 23481-041-020)	1	Z50M-100001	Z50M-103163	8012
	23481-041-020	GEAR, top, counter shaft	1	Z50M-103164		7024
8	23800-045-000	SPROCKET, drive	1	Z50M-100001		
9	23802-041-000	PLATE, drive sprocket fixing	1	Z50M-100001		
10	23911-041-000	COLLAR, gear	1	Z50M-100001	Z50M-103163	
	23911-041-010	COLLAR, gear	1	Z50M-103164		7024
11	90084-041-000	BOLT, drive sprocket fixing	2	Z50M-100001		
12	90451-001-000	WASHER, thrust	1	Z50M-100001		
13	90451-035-000	WASHER, thrust, 13.5mm	1	Z50M-100001		
14	90461-001-000	WASHER, spline, 17 mm	3	Z50M-100001		
15	90601-001-000	CIR-CRIP, 17 mm	4	Z50M-100001		
16	91203-035-000	OIL-SEAL, 17-29-5.....	1	Z50M-100001		
17	96100-62030	BEARING, ball, 6203.....	2	Z50M-100001		

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	24430-041-000	STOPPER, shift drum	1	Z50M-100001		
2	24435-040-000	SPRING, shift drum stopper	1	Z50M-100001		
3	24610-040-010	SPINDLE, gear shift	1	Z50M-100001	Z50M-101200	
	24610-040-020	SPINDLE, gear shift	1	Z50M-101201		7023
4	24630-040-000	ARM, gear shift	1	Z50M-100001	Z50M-101200	
	24630-040-010	ARM, gear shift	1	Z50M-101201	Z50M-103163	
	24630-040-040	ARM, gear shift	1	Z50M-103164		7024
5	24641-041-000	SPRING, gear shift arm	1	Z50M-100001		7037
6	24651-001-000	(Superseded by 24651-035-000)	1			
	24651-035-000	SPRING, gear shift return	1	Z50M-100001	Z50M-104279	
	24651-041-000	SPRING, gear shift return	1	Z50M-104280		8009
7	24652-035-000	PIN, shift return spring.....	1	Z50M-100001		
8	28211-040-010	PINION, kick starter	1	Z50M-100001	Z50M-101200	
8-1	28211-040-020	PINION, kick starter	1	Z50M-101201	Z50M-104540	7015
8-2	28211-040-035	PINION, kick starter	1	Z50M-104541		8018
9	28221-035-040	RATCHET, kick starter	1	Z50M-100001	Z50M-101200	7015
10	28223-035-010	SPRING, kick starter ratchet	1	Z50M-100001	Z50M-101200	
10-1	28223-035-020	SPRING, kick starter ratchet	1	Z50M-101201	Z50M-104540	7015
	28223-035-035	SPRING, kick starter ratchet	1	Z50M-104541		8018
11	28251-035-030	SPINDLE, kick starter	1	Z50M-100001	Z50M-101200	
11-1	28251-040-000	SPINDLE, kick starter	1	Z50M-101201	Z50M-104540	7015
	28251-035-065	SPINDLE, kick starter	1	Z50M-104541		8018
12	28262-035-020	RETAINER, kick spring	1	Z50M-100001		
13	28281-035-010	SPRING, kick starter	1	Z50M-100001		
14	90023-041-000	PIVOT, shift drum stopper arm.....	1	Z50M-100001		W/009
15	90451-040-000	WASHER, thrust, 17 mm	1	Z50M-100001		
16	90482-035-000	WASHER, 25 mm	1	Z50M-100001	Z50M-101200	
16-1	90482-035-010	WASHER, 25 mm	1	Z50M-101201	Z50M-104540	7015
16-2	90482-035-025	WASHER, 20 mm	1	Z50M-104541		8018
17	90601-035-000	CIR-CLIP, 22.5 mm.....	1	Z50M-100001	Z50M-101200	7015
18	90602-035-000	CIR-CLIP, 25 mm	1	Z50M-100001	Z50M-101200	7015
19	90601-001-000	CIR-CLIP, 17 mm	1	Z50M-104541		8018
20	90605-200-000	SET-RING, 20 mm	2	Z50M-104541		8018
21	94510-16100	CIR-CLIP, 16 mm	1	Z50M-100001		
22	94510-25000	CIR-CLIP, 25 mm	2	Z50M-101201	Z50M-104540	7015







E-10 Gear Shift**HONDA**

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	11926-020-000	PLUG, sealing, 10 mm	1	Z50M-100001	Z50M-112880	
2	24211-041-000	FORK, gear shift, left	2	Z50M-100001	Z50M-103163	
		FORK, gear shift, left	1	Z50M-103164		7024
3	24221-041-000	FORK, gear shift, right	1	Z50M-103164		7024
4	24261-028-010	PIN, shift fork guide	2	Z50M-100001		W/009
5	24263-028-000	CLIP, gear shift fork guide pin	2	Z50M-100001		
6	24301-041-000	DRUM, gear shift	1	Z50M-100001	Z50M-101200	
	24301-041-010	DRUM, gear shift	1	Z50M-101201	Z50M-103163	7022
	24301-041-060	DRUM, gear shift	1	Z50M-103164		7024
7	24421-200-000	PIN, gear shift drum	4	Z50M-100001	Z50M-103163	
	24421-041-000	PIN, gear shift drum	4	Z50M-103164		7024
8	24425-041-000	PLATE, drum stopper	1	Z50M-100001	Z50M-103163	
	24411-041-020	PLATE, drum stopper	1	Z50M-103164		8010
9	35755-001-020	PLATE, contact fixing	1	Z50M-100001	Z50M-112880	
10	90417-041-000	WASHER, side, shift drum	1	Z50M-100001		
11	90484-045-000	WASHER, 13.2 mm	1	Z50M-100001	Z50M-101200	
	90484-045-010	WASHER, 13.2 mm	1	Z50M-101201		7022
12	90801-035-000	PLUG, rubber, 19 mm	1	Z50M-100001		
13	92000-06016	BOLT, hex., 6×16	1			
14	93500-06012	SCREW, cross, 6×12	1			
15	93600-06016	SCREW, cross, 6×16	1			

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	11341-045-000	(Superseded by 11341-045-020 with 93500-06020 (2) and 93500-06036 (1))	1	Z50M-100001	Z50M-101200	
	11341-045-020	COVER, left crankcase	1	Z50M-101201		7018
2	24701-045-010	PEDAL, gear change	1	Z50M-100001		
3	30202-041-005	BREAKER, contact	1	Z50M-100001		
4	30205-041-005	FELT, oil	1	Z50M-100001		
5	30250-041-005	CONDENSER	1	Z50M-100001		
6	30540-041-005	COIL, primary	1	Z50M-100001		
	31100-045-622	A.C. GENERATOR ASSY., flywheel ... (Used in France)	1	Z50M-100001		W/003
	31100-045-602	A.C. GENERATOR ASSY., flywheel ... (Used in England)	1	Z50M-100001	Z50M-104950	W/003
	31100-045-603	A.C. GENERATOR ASSY., flywheel ... (Used in England)	1	Z50M-104951		8007
	31141-045-622	STATOR ASSY. (Used in France)	1	Z50M-100001		W/003
	31141-045-602	STATOR ASSY. (Used in England)	1	Z50M-100001	Z50M-104950	W/003
	31141-045-603	STATOR ASSY. (Used in England)	1	Z50M-104951		8007
7	31121-045-601	FLYWHEEL	1	Z50M-100001		W/006
8	31631-045-622	COIL, light (Used in France)	1	Z50M-100001		W/003
	31631-045-602	COIL, light (Used in England)	1	Z50M-100001		W/003
9	32971-035-000	GROMMET, cord	1	Z50M-100001		
10	90426-035-000	WASHER, magneto fixing	1	Z50M-100001		
11	91202-035-000	OIL-SEAL, 18.9×30×5	1	Z50M-100001		
12	91203-001-000	OIL-SEAL, S11.6-24-10	1	Z50M-100001		
13	91301-035-000	O RING, 107×2	1	Z50M-100001		
14	91317-703-000	O RING, 6×1.7	2	Z50M-100001		
15	92000-06020	BOLT, hex., 6×20	1			
16	93500-06020	SCREW, cross, 6×20	2			7018
17	93500-06036	SCREW, cross, 6×36	1			7018
18	93600-06016	SCREW, cross, 6×16	2			
19	94001-10000	NUT, hex., 10 mm	1			







E-12 Carburetor**HONDA**

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
	16100-045-020	CARBURETOR ASSY.	1	Z50M-100001	Z50M-100999	7030
	16100-045-600	CARBURETOR ASSY.	1	Z50M-101000		7031
1	16118-045-004	ADJUSTER, cable	1	Z50M-100001		
2	16119-045-004	TOP	1	Z50M-100001		
3	16122-049-004	FLOAT	1	Z50M-100001		
4	16123-049-004	COVER, choke	1	Z50M-100001		
5	16125-045-004	VALVE-SET, float	1	Z50M-100001		
6	16126-011-004	PIN, float arm	1	Z50M-100001		
7	16133-045-004	JET, needle	1	Z50M-100001		
8	16139-045-004	HOLDER, needle jet	1	Z50M-100001		
9	16141-045-004	VALVE, throttle	1	Z50M-100001		
10	16142-001-004	VALVE, choke	1	Z50M-100001		
11	16143-050-004	LINK, choke	1	Z50M-100001		
12	16151-045-004	NEEDLE, jet	1	Z50M-100001		
13	16156-001-004	PLATE, needle clip	1	Z50M-100001		
14	16157-259-004	CLIP, bar	1	Z50M-100001		
15	16162-049-004	SCREW, air	1	Z50M-100001		
16	16163-049-004	SCREW, throttle stop	1	Z50M-100001		
17	16164-045-004	SCREW, drain	1	Z50M-100001		
18	16171-049-004	WASHER, top	1	Z50M-100001		
19	16172-049-004	WASHER, float chamber	1	Z50M-100001		
20	16173-023-004	O RING, 150R	1	Z50M-100001		
21	16174-045-004	O RING, 38R	1	Z50M-100001		
22	16178-049-004	SEAL	1	Z50M-100001		
23	16179-049-004	SEAT, sealing	1	Z50M-100001		
24	16181-001-004	SPRING, air screw	2	Z50M-100001		
25	16185-045-004	SPRING, throttle	1	Z50M-100001		
26	16187-045-004	CLIP, float chamber set	1	Z50M-100001		
27	16188-049-004	WASHER, fiber	1	Z50M-100001		
28	16192-045-004	LEVER, choke	1	Z50M-100001		

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
29	16194-045-004	CAP, rubber	1	Z50M-100001		
30	16197-049-004	WASHER, stopper	1	Z50M-100001		
31	16198-045-004	PACKING, choke cover	1	Z50M-100001		
32	93500-03008	SCREW, cross, 3×8	2			
33	94001-05000	NUT, hex., 5 mm.....	1			
34	94101-05000	WASHER, flat 5 mm	1			
35	94111-03000	WASHER, spring, 3 mm	2			
36	94111-05000	WASHER, spring, 5 mm	1			
37	99124-04504	JET, main, #45	1			
	99124-04804	JET, main, #48	1			
	99124-05004	JET, main, #50 (S.T.D.)	1			
	99124-05204	JET, main, #52	1			
	99124-05504	JET, main, #55	1			
38	99153-03804	JET, slow, #38 (S.T.D.)	1			
	99153-04004	JET, slow, #40	1			







F-1 Steering Handle

HONDA

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	17910-045-030	CABLE, throttle	1	Z50M-100001		
2	17911-023-000	GROMMET, throttle wire..... (Used in France)	1	Z50M-100001		
3	35250-045-621	SWITCH ASSY., horn button w/dimmer (Used in France)	1	Z50M-100001		8015
	35250-045-013	SWITCH ASSY., horn button..... (Used in England)	1	Z50M-100001		8015
4	35317-028-300	KNOB, dimmer switch (Used in France)	1	Z50M-100001		
5	35317-230-000	BUTTON, horn button push	1	Z50M-100001		
6	35318-230-000	SPRING, horn button.....	1	Z50M-100001		
7	45437-001-000	SPRING, front brake arm.....	1	Z50M-100001		
8	45450-045-010	WIRE, front brake	1	Z50M-100001		
9	45461-001-000	JOINT, front brake arm	1	Z50M-100001		
10	45462-001-000	NUT, front brake arm adjust	1	Z50M-100001		
11	53110-045-040	PIPE, right steering handle	1	Z50M-100001		
12	53120-045-040	PIPE, left steering handle.....	1	Z50M-100001		
13	53141-044-000	PIPE, throttle grip	1	Z50M-100001		
14	53161-044-000	HINGE, throttle wire	1	Z50M-100001		
15	53162-044-000	HOLDER, outer, throttle wire.....	1	Z50M-100001		
16	53163-044-000	STOPPER, throttle grip pipe	1	Z50M-100001		
17	53165-044-010	RUBBER, right grip	1	Z50M-100001		
18	53166-044-010	RUBBER, left grip	1	Z50M-100001		
19	53175-045-010	LEVER, steering handle	1	Z50M-100001	Z50M-107534	
	53175-045-020	LEVER, steering handle	1	Z50M-107535		8017
20	88110-045-000	MIRROR, back, right.....	1	Z50M-100001		
21	88120-045-611	MIRROR, back, left (Used in France) ...	1	Z50M-100001		W/002
22	88130-045-600	BRACKET, back mirror	1	Z50M-100001		
		(Used in France)				
23	90101-044-000	SCREW, throttle grip set	1	Z50M-100001		
24	90114-028-000	SCREW, handle lever pivot.....	1	Z50M-100001		
25	93500-05024	SCREW, cross, 5×24.....	2			
26	94001-06000	NUT, hex., 6 mm.....	1			
27	94001-08000	NUT, hex., 8 mm.....	1			
28	94111-08000	WASHER, spring, 8 mm	1			
29	95010-16000	CAP, A-type control lever	1	Z50M-100001	Z50M-107534	8017

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	32101-045-620	HARNESS, horn (Used in France)	1	Z50M-100001		
2	38100-045-010	HORN (Used in England)	1	Z50M-100001		
3	51100-045-030C	FORK, front (Scarlet).....	1	Z50M-100001		
	51100-045-030Z	FORK, front (Base coating)	1	Z50M-100001		
4	53131-045-030	HOLDER, steering handle	1	Z50M-100001		
5	53143-045-000	NUT, handle holder	2	Z50M-100001		
6	53211-045-010	RACE, steering top cone	1	Z50M-100001		
7	53212-045-020	RACE, steering bottom cone	1	Z50M-100001		
8	53741-045-020	KNOB, handle holder.....	2	Z50M-100001		
9	53746-045-010	RING, knob stopper	2	Z50M-100001		
10	61100-045-000XL	FENDER, front	2	Z50M-100001		
11	84701-045-601B	PLATE, front number (Used in England)	1	Z50M-100001		
12	90303-045-000	NUT A, steering stem	1	Z50M-100001		
13	90304-011-000	NUT, steerig stem	1	Z50M-100001		
14	90304-045-010	NUT B, steering stem	1	Z50M-100001		
15	90522-034-000	WASHER, head light setting	4	Z50M-100001		
16	90503-011-000	WASHER, steering stem nut	1	Z50M-100001		
17	90521-268-810	WASHER, 6 mm	2	Z50M-100001		
18	92000-06012	BOLT, hex., 6×12	4			
19	92000-06020	BOLT, hex., 6×20	2			
20	92000-10025	BOLT, hex., 10×25.....	2			
21	94001-06000	NUT, hex., 6 mm.....	2			
22	94101-06000	WASHER, flat, 6 mm	2			
23	94101-10000	WASHER, flat, 10 mm	2			
24	96211-06000	BALL, steel, #6.....	40	Z50M-100001		







F-3 Fuel Tank

HONDA

Ref. No.	Part No.	Description	No. Reqd.	No. Used on		News No.
				From	To	
	16950-044-004	COCK ASSY., fuel	1	Z50M-100001		
1	16953-044-004	LEVER, cock.....	1	Z50M-100001		
2	16958-044-004	PACKING, turn buckle nut	1	Z50M-100001		
3	16960-044-004	SPRING, valve	1	Z50M-100001		
4	16962-044-004	NUT, turn buckle	1	Z50M-100001		
5	16963-044-004	SCREW, lever stopper	1	Z50M-100001		
6	16997-044-004	O RING	1	Z50M-100001		
7	17500-045-020XL	TANK, fuel (Ivory white).....	1	Z50M-100001	Z50M-112630	8019
	17500-045-020Z	TANK, fuel (Base coating)	1	Z50M-100001	Z50M-112630	
	17500-045-030XL	TANK, fuel (Ivory white).....	1	Z50M-112631		8020
	17500-045-030Z	TANK, fuel (Base coating)	1	Z50M-112631		8020
8	17611-045-020	CUSHION, front, fuel tank	2	Z50M-100001		
9	17613-045-000	CUSHION, rear, fuel tank	1	Z50M-100001		
10	17620-045-010	CAP, fuel filler	1	Z50M-100001		
11	17631-045-000	PACKING, fuel filler cap	1	Z50M-100001		
12	17670-045-010	BAND, fuel tank setting	1	Z50M-100001		
	87121-035-000	EMBLEM, right, fuel tank	1	Z50M-100001	Z50M-112630	
	87121-051-693	EMBLEM, right, fuel tank	1	Z50M-112631		8020
13	87122-035-000	EMBLEM, left, fuel tank	1	Z50M-100001	Z50M-112630	
	87122-051-693	EMBLEM, left, fuel tank	1	Z50M-112631		8020
14	93500-030082	SCREW, cross, 3×8	2			
	93700-0300832	SCREW, oval, 3×8.....	2			8020
15	95001-45100	TUBE, fuel feed, 4.5×100.....	1	Z50M-100001		
16	95002-45000	CLIP, fuel tube, 4.5.....	2	Z50M-100001		

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	77100-045-020A	SEAT	1	Z50M-100001		
2	77107-045-000C	BRACKET, right, front, seat (Scarlet) ...	1	Z50M-100001		
	77107-045-000Z	BRACKET, right, front, seat (Base coating)	1	Z50M-100001		
3	77108-045-020C	BRACKET, right, rear, seat (Scarlet) ...	1	Z50M-100001		
	77108-045-020Z	BRACKET, right, rear, seat (Base coating)	1	Z50M-100001		
4	77109-045-000C	BRACKET, left, front, seat (Scarlet)	1	Z50M-100001		
	77109-045-000Z	BRACKET, left, front, seat (Base coating)	1	Z50M-100001		
5	77110-045-000C	BRACKET, left, rear, seat (Scarlet)	1	Z50M-100001		
	77110-045-000Z	BRACKET, left, rear, seat (Base coating)	1	Z50M-100001		
6	77111-045-010B	BRACKET A, under, seat	1	Z50M-100001		
7	77112-045-020	PIN, seat lock	1	Z50M-100001		
8	77113-045-010	SPRING, seat lock	1	Z50M-100001		
9	77114-045-020	STOPPER, seat	1	Z50M-100001		
10	77116-045-000	RUBBER A, seat stopper	1	Z50M-100001		
11	77117-045-000	CATCHER, seat	1	Z50M-100001		
12	77118-045-000B	BRACKET B, under, seat	1	Z50M-100001		
13	77119-045-000	RUBBER, seat stopper	1	Z50M-100001		
14	92000-06012	BOLT, hex., 6×12	6			
15	94001-06000	NUT, hex., 6 mm.....	4			
16	94101-06000	WASHER, flat, 6 mm	6			
17	94201-20150	PIN, cotter, 2.0×15.....	2			







F-5 Frame Body · Air Cleaner**HONDA**

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	17211-045-030	ELEMENT, air cleaner	1	Z50M-100001		
2	17212-045-000	PIPE, inner, air cleaner.....	1	Z50M-100001		
3	17221-045-020C	CASE, air cleaner (Scarlet)	1	Z50M-100001		
4	17231-045-030	COVER, air cleaner case	2	Z50M-100001		
5	17252-045-300	PACKING, air cleaner case.....	2	Z50M-100001		
6	17255-045-000	BAND, air cleaner connecting tube	1	Z50M-100001		
7	50100-045-620C	BODY, frame (Scarlet) (Used in France) .	1	Z50M-100001		
	50100-045-620Z	BODY, frame (Base coating)	1	Z50M-100001		
		(Used in France)				
	50100-045-600C	BODY, frame (Scarlet)	1	Z50M-100001		
		(Used in Englang)				
	50100-045-600Z	BODY, frame (Base coating)	1	Z50M-100001		
		(Used in England)				
8	50301-044-020	RACE, steering top ball	2	Z50M-100001		
9	87125-041-680	PLATE, name	1	Z50M-100001		7027
10	87501-045-620	PLTE, registered (Used in France)	1	Z50M-100001		
11	90841-001-000	RIVET, screw, 1.5×5 (Used in France) .	2	Z50M-100001		
12	92000-05008	BOLT, hex., 5×8.....	1			
13	92000-05020	BOLT, hex., 5×20	1			
14	92000-08098	BOLT, hex., 8×98	1			
15	92000-08109	BOLT, hex., 8×109.....	1			
16	93500-0613502	SCREW, cross., 6×135	1			
17	94001-08000	NUT, hex., 8 mm.....	2			
18	94021-06020	NUT, blind, 6 mm	1			
19	94101-05000	WASHER, flat, 5 mm	1			
20	94111-08000	WASHER, spring, 8 mm	2			

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	18233-040-010	COLLAR, exhaust pipe joint	2	Z50M-100001		
2	18240-045-600	COVER, exhaust pipe.....	1	Z50M-100001		
3	18291-001-010	GASKET, exhaust pipe	1	Z50M-100001		
4	18300-045-600	MUFFLER, exhaust	1	Z50M-100001		
5	40510-045-020C	CASE, drive chain (Scarlet).....	1	Z50M-100001		
	40510-045-020Z	CASE, drive chain (Base coating)	1	Z50M-100001		
6	45436-001-000	NUT, front brake arm setting	1	Z50M-100001		
7	46500-045-030	PEDAL, brake	1	Z50M-100001		
8	46501-045-040	ARM, middle, brake arm	1	Z50M-100001		
9	46514-045-030	SPRING, brake pedal.....	1	Z50M-100001		
10	50542-045-010	SPRING, side stand	1	Z50M-100001		
11	50610-045-020	BAR, step	1	Z50M-100001		
12	50701-024-010	BAR, pillion step	2	Z50M-100001		
13	50705-024-000	RUBBER, pillion step.....	2	Z50M-100001		
14	50712-024-000	WASHER, pillion step	2	Z50M-100001		
15	50715-024-000	PIN, pillion step	2	Z50M-100001		
16	90525-001-000	WASHER, brake arm.....	1	Z50M-100001		
17	92000-06012	BOLT, hex., 6×12	3			
18	92000-06028	BOLT, hex., 6×28	1			
19	92000-08020	BOLT, hex., 8×20	4			
20	92045-08045	BOLT, hex., 8×45	1			
21	93500-05004	SCREW, cross, 5×4	2			
22	93500-06006	SCREW, cross, 6×6	1			
23	94001-06000	NUT, hex., 6 mm.....	2			
24	94002-08000	NUT, thin, 8 mm	2			
25	94101-06000	WASHER, flat, 6 mm	6			
26	94111-08000	WASHER, spring 8 mm.....	4			
27	94201-16150	PIN, cotter, 1.6×15.....	2			







F-7 Tool · Tail Light

HONDA

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	32983-011-000	GROMMET, wire cord	1	Z50M-100001		
	33700-045-000	LIGHT ASSY., tail (Used in France) ...	1	Z50M-100001		
	33700-045-601	LIGHT ASSY., tail (Used in England)...	1	Z50M-100001	Z50M-104950	
	33700-045-602	LIGHT ASSY., tail (Used in England)...	1	Z50M-104951		8006
2	33701-268-680	LENS, tail light (Used in France)	1	Z50M-100001		
	33701-268-600	LENS, tail light (Used in England)	1	Z50M-100001		
3	33703-045-000	SOCKET, tail light (Used in France) ...	1	Z50M-100001		
	33703-045-601	SOCKET, tail light (Used in England)...	1	Z50M-100001	Z50M-104950	
	33703-045-000	SOCKET, tail light (Used in England)...	1	Z50M-104951		8006
4	33705-268-670	PLATE, tail light lens holder	1	Z50M-100001		
5	33709-268-810	PACKING, tail light lens	1	Z50M-100001		
6	34906-202-610	BULB, tail light (Used in France)	1	Z50M-100001		
	34906-202-830	BULB, tail light (Used in England)	1	Z50M-100001		
7	80100-045-010XL	FENDER, rear	1	Z50M-100001		
8	83500-045-000C	BOX, tool (Scarlet)	1	Z50M-100001	Z50M-100239	
	83500-045-000Z	BOX, tool (Base coating)	1	Z50M-100001	Z50M-100239	
	83500-045-010C	BOX, tool (Scarlet)	1	Z50M-100240		W/005
	83500-045-010Z	BOX, tool (Base coating)	1	Z50M-100001		W/005
9	83541-045-000C	CAP, tool box (Scarlet)	1	Z50M-100001		
	83541-045-000Z	CAP, tool box (Base coating)	1	Z50M-100001		
10	84700-045-010C	BRACKET, number plate (Scarlet)	1	Z50M-100001		
	84700-045-010Z	BRACKET, number plate (Base coating)	1	Z50M-100001		
	89010-045-000	TOOL-SET	1			
11	89101-011-000	BAG, tool	1			7037
12	89211-001-000	WRENCH, box, 9 mm	1			
	89203-200-000	SPANNER, 9 mm	1			8011
13	89215-001-000	WRENCH, socket, 3 mm	1			
14	89216-200-000	WRENCH, spark plug	1			
	89216-045-000	WRENCH, spark plug	1			8011
15	89218-045-000	WRENCH, box, 19 mm	1			

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
	89212-028-000	SPANNER, box, 17 mm.....	1			8011
16	89231-001-000	GAUGE, tappet clearance adjust	1			
17	89423-045-000	JOINT, valve.....	1			
18	90522-034-000	WASHER, head light case setting	4			
19	90563-045-000	WASHER, number bracket mount.....	1			
20	92000-06012	BOLT, hex., 6×12	4			
21	92000-06016	BOLT, hex., 6×16	1			
22	93500-04010	SCREW, cross, 4×10.....	2			
23	93700-03060	SCREW, cross, 3×60.....	2			
24	94001-06000	NUT, hex., 6 mm.....	1			
25	94202-20250	PIN, cotter, 2.0×25.....	1			
26	99001-10140	SPANNER, 10×14	1			
27	99002-13500	PLIERS, 135	1			
28	99003-10000	DRIVER, No. 2, plus.....	1			
29	99003-20000	DRIVER, No. 3, plus.....	1			
30	99003-30000	DRIVER, No. 2, minus.....	1			
31	99003-50000	GRIP	1			





F-8 Front Wheel


HONDA


Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	42701-045-010	RIM, wheel	1	Z50M-100001		
2	44301-045-000	AXLE, front wheel	1	Z50M-100001		
3	44600-045-030	HUB, front wheel	1	Z50M-100001		
4	44620-045-010	COLLAR, front axle distance	1	Z50M-100001		
5	44711-045-000	TIRE, wheel	1	Z50M-100001		
6	44712-045-000	TUBE, wheel.....	1	Z50M-100001		
7	44800-045-010	BOX, speedometer gear.....	1	Z50M-100001		
8	44830-045-620	CABLE, speedometer (Used in France)	1	Z50M-100001		
	44830-045-010	CABLE, speedometer (Used in England)	1	Z50M-100001		
9	44831-045-010	CABLE, inner, speedometer.....	1	Z50M-100001		
10	45100-045-020	PANEL, front brake	1	Z50M-100001		
11	45120-001-010	SHOE, brake.....	2	Z50M-100001		
12	45131-045-000	CAM, front brake	1	Z50M-100001		
13	45133-001-010	SPRING, brake shoe	2	Z50M-100001		
14	45410-045-000	ARM, front brake	1	Z50M-100001		
15	45436-001-000	NUT, front brake arm setting.....	1	Z50M-100001		
16	90353-250-000	NUT, self lock, 12 mm	1	Z50M-100001		
17	90525-001-000	WASHER, brake arm	1	Z50M-100001		
18	91252-001-020	SEAL, oil 21355.5	1	Z50M-100001		8014
19	92000-06016	BOLT, hex., 6×16	4			
20	94101-12000	WASHER, flat, 12 mm	1			
21	94111-06000	WASHER, spring, 6 mm	4			
22	94520-32000	CIR-CLIP, internal, 32φ	1			
23	96100-62010	BEARING, ball, 6201	1			8022
24	96140-62010	BEARING, ball, 6201R	1			8022
25	92000-06025	BOLT, hex., 6×25	1			

~~47099-FF~~
44711-032-009

224, - HT

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	40530-045-010	CHAIN, drive (DK415)	1	Z50M-100001		
2	40531-045-010	JOINT, drive chain.....	1	Z50M-100001		
3	40543-032-000	ADJUSTER, drive chain	2	Z50M-100001		
4	41201-045-020	SPROCKET, final driven	1	Z50M-100001		
5	41209-032-000	BOLT, driven sprocket clamp	3	Z50M-100001		
6	42301-045-000	AXLE, rear wheel	1	Z50M-100001		
7	42311-045-000	COLLAR, rear wheel side	1	Z50M-100001		
8	42601-045-030	HUB, rear wheel.....	1	Z50M-100001		
9	42620-045-010	COLLAR, rear axle distance	1	Z50M-100001		
10	42701-045-010	RIM, wheel	1	Z50M-100001		
11	43100-045-030	PANEL, rear brake.....	1	Z50M-100001		8022
12	43141-045-000	CAM, rear brake.....	1	Z50M-100001		
13	43411-045-030	ARM, rear brake.....	1	Z50M-100001		
14	44711-045-000	TIRE, wheel	1	Z50M-100001		
15	44712-045-000	TUBE, wheel.....	1	Z50M-100001		
16	45120-001-010	SHOE, brake.....	2	Z50M-100001		
17	45133-001-010	SPRING, brake shoe	2	Z50M-100001		
18	45436-001-000	NUT, front brake arm setting.....	1	Z50M-100001		
19	90353-250-000	NUT, self lock, 12 mm	1	Z50M-100001		
20	90522-045-000	WASHER, tongued, 8 mm	3	Z50M-100001		
21	90525-001-000	WASHER, brake arm	1	Z50M-100001		
22	91251-045-005	SEAL, oil, 18328	1	Z50M-100001		8014
23	92000-06016	BOLT, hex., 6×16	4			
24	92000-06025	BOLT, hex., 6×25	1			
25	94001-06000	NUT, hex., 6 mm.....	2			
26	94101-06000	WASHER, flat, 6 mm.....	2			
27	94111-06000	WASHER, spring, 6 mm	6			
28	96100-62010	BEARING, ball, 6201	1			8022
29	96140-62010	BEARING, ball, 6201R	1			8022







F-10 Head Light • Wire Harness

HONDA

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
1	30400-045-020	COIL, ignition	1	Z50M-100001		
2	30700-259-600	CAP, noise suppressor	1	Z50M-100001		
3	32100-045-620	HARNESS, wire (Used in France)	1	Z50M-100001		
	32100-045-600	HARNESS, wire (Used in England)	1	Z50M-100001	Z50M-104950	
	32100-045-030	HARNESS, wire (Used in England)	1	Z50M-104951		8006
4	32110-045-620	HARNESS B, wire (Used in France) ...	1	Z50M-100001		W/002
5	32161-001-000	BAND, wire harness	1	Z50M-100001	Z50M-101576	
		BAND, wire harness	2	Z50M-101577		7017
6	32161-045-000	BAND C, wire harness	1	Z50M-100001	Z50M-101576	7017
	33100-051-621	LIGHT ASSY., head (Used in France)...	1	Z50M-100001		
	33100-045-601	LIGHT ASSY., head (Used in England)	1	Z50M-100001		
7	33101-051-621	LIM, head light (Used in France)	1	Z50M-100001		
	33101-045-601	LIM, head light (Used in England)	1	Z50M-100001		
8	33108-028-010	SPRING, supporter (Used in France) ...	3	Z50M-100001		
	33108-045-601	SPRING, supporter (Used in England)...	3	Z50M-100001		
9	33121-051-621	LIGHT UNIT, head (Used in France)...	1	Z50M-100001		
	33121-045-601	LIGHT UNIT, head (Used in Englang)	1	Z50M-100001		
10	33130-051-621	SOCKET, head light (Used in France)...	1	Z50M-100001		
	33158-045-601	CORD, earth (Used in England)	1	Z50M-100001		
11	34901-045-601	BULB, head light (Used in England).....	1	Z50M-100001		W/002
12	34908-001-000	BULB, speedometer	1	Z50M-100001		
13	35100-045-622	SWITCH, combination (Used in France)	1	Z50M-100001		7032
	35100-045-003	SWITCH, combination (Used in England)	1	Z50M-100001	Z50M-104950	7032
	35100-045-601	SWITCH, combination (Used in England)	1	Z50M-104951		8006
14	35350-045-020	SWITCH ASSY., stop	1	Z50M-100001		8006
15	35357-045-020	SPRING, stop switch	1	Z50M-100001		8006

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
16	37200-045-000	SPEEDOMETER ASSY. (Used in France)	1	Z50M-100001		
	37200-045-601	SPEEDOMETER ASSY. (Used in England)	1	Z50M-100001		
17	37203-045-000	SOCKET, speedometer	1	Z50M-100001		
18	37244-045-000	SPRING, meter set	1	Z50M-100001		
19	61301-045-622C	CASE, head light (Scarlet) (Used in France)	1	Z50M-100001		
	61301-045-622Z	CASE, head light (Base coating) (Used in France)	1	Z50M-100001		
	61301-045-000C	CASE, head light (Scarlet) (Used in England)	1	Z50M-100001		
	61301-045-000Z	CASE, head light (Base coating) (Used in England)	1	Z50M-100001		
20	61302-268-020	GROMMET, 25 mm	2	Z50M-100001		
21	92000-05020	BOLT, hex., 5×20	2			
22	92000-08014	BOLT, hex., 8×14 (Used in England) ...	2			
	92000-08028	BOLT, hex., 8×28 (Used in France).....	2			
23	93700-0501202	SCREW, cross, 5×12.....	3			
24	94101-08000	WASHER, flat, 8 mm.....	2			





Y Support Stand**HONDA**

Ref. No.	Part No.	Description	No. Req'd.	No. Used on		News No.
				From	To	
	06880-045-000	ACCESSORY SET, support.....	1			7011
1	88801-045-810	STAND, frame support.....	1			7011
2	88802-045-810	STAND, rear support.....	1			7011
3	88803-045-810	STAND, front support	1			7011
4	88804-045-810	RUBBER A, support stand	3			7011
5	88805-045-810	RUBBER B, support stand	1			7011
6	88806-045-810	PIN, support stand	1			7011
7	88807-045-810	BAG, support stand.....	1			7011
8	88808-045-810	NUT, frame support	1			7011

PART NO. INDEX

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
00000 Parts		13115-001-000.....	4	15332-035-000.....	16	16963-044-004.....	35
06880-045-000.....	55	13201-036-000.....	4	15382-035-000.....	16	16997-044-004.....	35
11000 Parts		13211-035-000.....	4	15383-035-000.....	16	17000 Parts	
11100-045-000.....	11	13310-035-030.....	4	15421-035-010.....	11	17111-045-030.....	3
11191-035-030.....	11	13310-035-050.....	4	15650-045-000.....	16	17111-045-040.....	3
11200-045-000.....	11	13321-041-010.....	4	15761-045-000.....	11	17211-045-030.....	39
11200-045-040.....	11	13321-041-020.....	4	16000 Parts		17212-045-000.....	39
11330-045-010.....	16	13381-035-010.....	4	16100-045-020.....	27	17221-045-020C ...	39
11341-045-020.....	24	14000 Parts		16100-045-600.....	27	17231-045-030.....	39
11394-035-000.....	16	14101-040-000.....	7	16118-045-004.....	27	17252-045-300.....	39
11926-020-000.....	23	14101-041-000.....	7	16119-045-004.....	27	17255-045-000.....	39
12000 Parts		14101-041-010.....	7	16122-049-004.....	27	17500-045-020XL	35
12021-035-811.....	7	14311-035-000.....	4	16123-049-004.....	27	17500-045-020Z ...	35
12023-051-310.....	7	14321-035-010.....	8	16125-045-004.....	27	17500-045-030XL	35
12101-041-030.....	3	14401-035-005.....	8	16126-011-004.....	27	17500-045-030Z ...	35
12101-041-680.....	3	14431-035-000.....	7	16133-045-004.....	27	17611-045-020.....	35
12191-035-010.....	3	14451-035-000.....	7	16139-045-004.....	27	17613-045-000.....	35
12200-036-020.....	3	14500-035-000.....	8	16141-045-004.....	27	17620-045-010.....	35
12200-041-020.....	3	14500-035-010.....	8	16142-001-004.....	27	17631-045-000.....	35
12251-036-000.....	3	14502-035-310.....	8	16143-050-004.....	27	17670-045-010.....	35
12251-036-010.....	3	14531-035-000.....	8	16151-045-004.....	27	17910-045-030.....	31
12301-035-000.....	3	14541-035-010.....	8	16156-001-004.....	27	17911-023-000.....	31
12331-035-000.....	3	14551-035-010.....	8	16157-259-004.....	27	18000 Parts	
12341-035-000.....	3	14551-035-020.....	8	16162-049-004.....	27	18233-040-010.....	40
12361-035-000.....	3	14566-035-000.....	8	16163-049-004.....	27	18240-045-600.....	40
12391-035-000.....	3	14591-035-010.....	8	16164-045-004.....	27	18291-001-010.....	40
12394-035-000.....	3	14610-035-010.....	8	16171-049-004.....	27	18300-045-600.....	40
12395-035-000.....	3	14615-035-000.....	8	16172-049-004.....	27	22000 Parts	
13000 Parts		14670-035-030.....	8	16173-023-004.....	27	22101-040-000.....	12
13000-041-010.....	4	14675-035-050.....	8	16174-045-004.....	27	22101-040-010.....	12
13000-041-030.....	4	14675-035-060.....	8	16178-049-004.....	27	22111-040-000.....	12
13010-036-000.....	4	14711-036-000.....	7	16179-049-004.....	27	22119-040-000.....	12
13020-036-000.....	4	14721-036-000.....	7	16181-001-004.....	27	22120-040-010.....	12
13030-036-000.....	4	14730-028-000.....	7	16185-045-004.....	27	22120-040-020.....	12
13040-036-000.....	4	14731-028-000.....	7	16187-045-004.....	27	22131-035-020.....	12
13050-036-000.....	4	14751-035-600.....	7	16188-049-004.....	27	22201-040-000.....	12
13101-036-010.....	4	14761-035-000.....	7	16192-045-004.....	27	22310-001-020.....	12
13102-036-010.....	4	14771-035-600.....	7	16194-045-004.....	28	22310-041-010.....	12
13103-036-010.....	4	14776-028-000.....	7	16197-049-004.....	27	22321-001-030.....	12
13104-036-010.....	4	14781-001-010.....	7	16198-045-004.....	27	22321-041-000.....	12
13105-036-010.....	4	15000 Parts		16201-040-000.....	3	22331-041-000.....	12
13111-036-000.....	4	15119-035-020.....	16	16201-045-000.....	3	22351-040-010.....	12
		15300-035-000.....	16	16211-045-000.....	3	22351-040-060.....	12
		15311-035-000.....	16	16211-045-010.....	3	22401-040-000.....	12
		15321-035-000.....	16	16236-045-000.....	11		
		15329-035-000.....	16	16950-044-004.....	35		
		15331-035-000.....	16	16953-044-004.....	35		
				16958-044-004.....	35		
				16960-044-004.....	35		
				16962-044-004.....	35		

PART NO. INDEX

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
22401-040-010.....	12	24301-041-060.....	23	30540-041-005.....	24	34000 Parts	
22411-001-010.....	12	24411-041-020.....	23	30700-259-600.....	51		34901-045-601..... 51
22411-041-000.....	12	24421-200-000.....	23	31000 Parts			34906-202-610..... 43
22421-040-000.....	12	24421-041-000.....	23				34906-202-830..... 43
22811-040-010.....	12	24425-041-000.....	23				34908-001-000..... 51
22811-040-020.....	12	24430-041-000.....	20			35000 Parts	
22820-041-000.....	12	24435-040-000.....	20	31100-045-602.....	24		35100-045-003..... 51
22820-046-000.....	12	24610-040-010.....	20	31100-045-603.....	24		35100-045-622..... 51
22825-046-000.....	12	24610-040-020.....	20	31100-045-622.....	24		35250-045-013..... 31
22830-041-000.....	16	24630-040-010.....	20	31121-045-601.....	24		35250-045-621..... 31
22846-040-000.....	16	24630-040-040.....	20	31141-045-602.....	24		35317-028-300..... 31
22860-041-000.....	12	24641-041-000.....	20	31141-045-603.....	24		35317-230-000..... 31
22901-001-000.....	12	24651-035-000.....	20	31141-045-622.....	24		35318-230-000..... 31
22901-040-000.....	12	24651-041-000.....	20	31631-045-602.....	24		35350-045-020..... 51
22911-035-010.....	4	24652-035-000.....	20	31631-045-622.....	24		35357-045-020..... 51
23000 Parts		24701-045-010.....	24	32000 Parts			35755-001-020..... 23
		25000 Parts				37000 Parts	
23110-036-000.....	12	25551-040-007.....	15	32100-045-030.....	51		37200-045-000..... 52
23112-041-000.....	15	25555-046-000.....	15	32100-045-600.....	51		37200-045-601..... 52
23112-041-030.....	15	28000 Parts		32100-045-620.....	51		37203-045-000..... 52
23120-036-010.....	15			32101-045-620.....	32		37244-045-000..... 52
23211-041-010.....	19			32110-045-620.....	51	38000 Parts	
23211-041-020.....	19			32161-001-000.....	51		
23221-041-000.....	19	28211-040-010.....	20	32161-045-000.....	51		
23221-041-010.....	19	28211-040-020.....	20	32971-035-000.....	24		
23221-041-040.....	19	28211-040-035.....	20	32983-011-000.....	43	40000 Parts	
23421-041-000.....	19	28221-035-040.....	20	33000 Parts			
23431-041-010.....	19	28221-035-040.....	20				
23431-041-030.....	19	28223-035-010.....	20				
23431-041-040.....	19	28223-035-020.....	20				
23441-041-000.....	19	28223-035-035.....	20	33100-045-601.....	51		40510-045-020C ... 40
23441-041-050.....	19	28251-035-030.....	20	33100-051-621.....	51		40510-045-020Z ... 40
23441-041-060.....	19	28251-035-065.....	20	33101-045-601.....	51		40530-045-010..... 48
23471-041-000.....	19	28251-040-000.....	20	33101-051-621.....	51		40531-045-010..... 48
23471-041-030.....	19	28262-035-020.....	20	33108-045-601.....	51	41000 Parts	40543-032-000..... 48
23471-041-040.....	19	28281-035-010.....	20	33108-028-010.....	51		
23481-041-020.....	19	28300-045-000.....	16	33121-045-601.....	51		
23800-045-000.....	19	28301-045-000.....	16	33121-051-621.....	51		
23802-041-000.....	19	28302-001-000.....	16	33130-051-621.....	51	42000 Parts	
23911-041-000.....	19	28303-001-000.....	16	33158-045-601.....	51		
23911-041-010.....	19	28311-001-000.....	16	33700-045-000.....	43		
24000 Parts		28322-001-000.....	16	33700-045-601.....	43		
		28324-001-000.....	16	33700-045-602.....	43		
		30000 Parts		33701-268-600.....	43		
				33701-268-680.....	43		
24211-041-000.....	23			33703-045-000.....	43	42000 Parts	
24221-041-000.....	23			33703-045-601.....	43		41201-045-020..... 48
24261-028-010.....	23	30202-041-005.....	24	33705-268-670.....	43		41209-032-000..... 48
24263-028-000.....	23	30205-041-005.....	24	33709-268-810.....	43		
24301-041-000.....	23	30250-041-005.....	24				
24301-041-010.....	23	30400-045-020.....	51				

PART NO. INDEX

[illegible]

PART NO. INDEX

[illegible]

HONDA MOTOR CO.,LTD.